



# Archive Player



**BOSCH**

en Operator's Manual



# Table of Contents

---

<b>1</b>	<b>Introduction</b>	<b>3</b>
1.1	About this Manual	3
1.2	Conventions in this Manual	3
1.3	Archive Player	3
1.4	System Requirements for Operation of Archive Player	4
1.5	Additional Documentation	5
<hr/>		
<b>2</b>	<b>Installation and Starting</b>	<b>7</b>
2.1	Installation	7
2.2	Starting the Program	7
2.2.1	Archive Player and VIDOS Server	7
2.2.2	Archive Player and VRM	8
2.3	Deinstallation	8
2.4	Licenses	9
2.5	Configuration with Configuration Manager	11
2.5.1	Export	12
2.5.2	Layout	13
2.5.3	IntuiKey Keyboard	13
2.5.4	Playback	14
2.5.5	VRM Server	14
2.6	Preparing for the Exchange of Encrypted Data	14
<hr/>		
<b>3</b>	<b>Operation</b>	<b>15</b>
3.1	User Interface	16
3.2	Main Menu	18
3.3	File Search	22
3.3.1	Setting a Filter	22
3.3.2	Search Results	24

---

3.4	Playback Controls	25
3.4.1	Timeline	25
3.4.2	Viewing the Selected Recording	28
3.4.3	Additional Information and Controls	29
3.4.4	Connection Between Monitor and Recording	30
3.5	Software Zoom	31
3.6	Motion Detection	32
3.6.1	Motion Detection with Camera Presets	34
3.6.2	Forensic Search	35
3.7	Export	37
3.7.1	Exporting Recordings	37
3.7.2	Export Markers	40
3.7.3	Possible Causes of Delays or Errors when Exporting	41
3.7.4	Additional Information	41
3.7.5	Burning Data to CD or DVD	42

---

<b>4</b>	<b>Index</b>	<b>43</b>
----------	--------------	-----------

# 1 Introduction

## 1.1 About this Manual

This manual is intended for persons who will configure and/or operate Archive Player. The manual describes how to operate Archive Player.

## 1.2 Conventions in this Manual

In this manual, the following symbols and notations are used to draw attention to special situations:



### CAUTION!

Security instructions where non-compliance can result in loss of data are marked with this symbol.

---



### NOTICE!

This symbol indicates special features and provides tips and information for easier, more convenient use of the software.

---

Terms that you can find in the program, such as menu options or commands, are written in **bold**.

## 1.3 Archive Player

Archive Player is a software that is used to play back and export recorded video sequences. Archive Player indicates the location at which recordings from a specific camera are archived in the system. Recordings can be selectively searched and played back.

If you manage your recordings with VRM Video Recording Manager, you can use Archive Player to view them.

Archive Player is extended by various motion detection algorithms (MOTION+, IVMD, IVA) that facilitate analysis of the recordings.

The export function also provides the option of exporting recordings or extracts from them and burning them onto CD or DVD for use elsewhere.

Together with Archive Player, the Configuration Manager program is also installed, which is used for configuring the system.

## 1.4 System Requirements for Operation of Archive Player

Operating system:	Windows XP Home Windows XP Professional
CPU:	Pentium IV, 3.0 GHz or faster
RAM:	256 MB or more
Graphics card:	NVIDIA GeForce 6600, 6800, 6800 GT, 7800 NVIDIA Quadro FX 1400, 4400 ATI RADEON X600, X750, X800, X850 or better
Network adapter:	100 Mbps
CD or DVD burner:	Recommended (to fully benefit from the export function)
Sound card:	Recommended
Software:	DirectX 9.0c
Hard drive space:(for installation)	120 MB (.NET environment, MPEG ActiveX, Archive Player)

## 1.5 Additional Documentation

Once Archive Player has been installed, this document is also available as online Help within the program. Depending on the configuration of your system, the following documentation may also be useful:

<b>Configuration Manager</b>	This configuration program is part of every Archive Player installation.
<b>VIDOS Server</b> <b>VRM</b> <b>IVMD</b> <b>IVA</b>	Each program is explained in a separate document.
<b>Forensic Search</b>	When you purchase a forensic search license, Bosch will provide you with comprehensive documentation for the configuration options.
<b>Camera documentation</b>	The manufacturer will provide you with separate documentation for each camera.
<b>VideoJet, VIP etc.</b> <b>NVR</b>	Bosch will provide you with documentation for each device. This explains the typical device settings.



## 2 Installation and Starting

### 2.1 Installation

The configuration program Configuration Manager and Player, the playback program for exported video data, are installed together with Archive Player.

If you want to use the Archive Player export function, you must activate the **Additional elements for export CDs** option during installation.

### 2.2 Starting the Program

After successful installation, you will find the following icons on your desktop:



- ▶ Double click an icon to start the relevant program. Archive Player can also be started via the Windows **Start menu** or from within the Configuration Manager program.

#### 2.2.1 Archive Player and VIDOS Server

If Archive Player is used on a system that uses VIDOS Server for managing devices and users, you have to log in when Archive Player starts up.

The login window will be displayed before the program starts. Enter your user name and password here.

Confirm your entries by pressing Enter.

All users who are to work with Archive Player under VIDOS Server require the **Recording menu** right. This right is activated in the Configuration Manager program under **System > Applications > VIDOS Server**.

For more information about user administration, please see the *VIDOS Server* documentation.

Login is not required if a server connection has already been established in the Configuration Manager program and Archive Player is started directly from within the program.

### 2.2.2 Archive Player and VRM

If Archive Player is used on a system that uses VRM Video Recording Manager for managing recordings, you have to log in when Archive Player starts up.

The login window will be displayed before the program starts.

Enter your user name and password here.

Confirm your entries by pressing Enter.

If required, VRM Configurator can be used to assign rights that restrict the use of some Archive Player functions.

For more information about this function, please see the *VRM Video Recording Manager* documentation.

## 2.3 Deinstallation

If you no longer want to use Archive Player on your PC, uninstall the program.

1. Click **Start > Settings > Control Panel**.
2. Double click **Add or Remove Programs**.
3. Select the **Bosch Archive Player** entry.
4. Click **Remove**.

## 2.4 Licenses

After installation, you can use the Archive Player program including the search and export functions as a demo version for a period of 30 days.

Archive Player itself (for playing back recorded files) can then still be used without a license. You will require a license for the additional export function for exporting files and saving to CD or DVD.

You will also require a license to continue using forensic search with the extended video analysis options (IVMD, IVA) in recordings. The motion detection base module (MOTION+) can also still be used without a license.

License management for Archive Player is carried out using the Configuration Manager program on the PC that is to be licensed.

1. Start the Configuration Manager program on the PC you want to license.
2. Click **Help > About...**
3. In the **About Configuration Manager** dialog box, click the **License** tab and then **License viewer...**  
You will see the **License Viewer** window.
4. Make a note of the second **Installation Code (Code 2)** – the copy-and-paste function is supported. You will need this to generate the activation keys for your license.

---

### NOTICE!



When you purchase products that require a license, you will receive a separate authorization number for each license and workstation; you will also need this number to generate the relevant activation keys.

- 
5. Open the following Website from any PC:  
<https://activation.boschsecurity.com/>  
The Bosch Security Systems Software License Manager user interface will appear. The page appears in English only.

6. If you already have an account, log in.  
You can create a new account if you wish. The benefit of an account is that you can list all of your previous license activations.  
Once you have logged in, the welcome dialog box will appear.  
You can also continue the process without logging in.  
Next, you will see the **License Activation** screen.
7. Generate the required activation keys.
8. Return to Configuration Manager.
9. Reopen the **License Viewer** window as described in steps 2 and 3.
10. Click **Activation Key** and enter the first activation key (**Activation Key 1**) – the copy-and-paste function is supported.
11. Click **OK** to save the activation key.
12. Repeat this process to save the second activation key (**Activation Key 2**).  
This releases the license version.

You can use the License Viewer at any time to determine which license version is active on the PC in question.

**CAUTION!**

The license is linked to your PC. If you have uninstalled Archive Player and then want to reinstall it on a different PC, you will need to request a new activation key.

---

## 2.5 Configuration with Configuration Manager

The Configuration Manager program is installed along with the Archive Player program. You can use Configuration Manager to integrate devices into the system and to configure devices and cameras.

**NOTICE!**

Archive Player can only access cameras and devices that have been integrated into the system using the Configuration Manager program.

**NOTICE!**

In systems in which recordings are managed with VRM Video Recording Manager, VRM Configurator handles most of these tasks. However, you will still need Configuration Manager to integrate Archive Player into the VRM system.


---

The Configuration Manager program comes complete with extensive documentation containing information about the use of the program.

The following settings, which exclusively affect Archive Player, are made in the Configuration Manager program:

1. In the Configuration Manager program, click the **System** tab on the left-hand side.

## 2. In the tree structure, select **Applications > Archive Player**.



### 2.5.1 Export

#### Default export path

Here you can select the path to the folder to which Archive Player will export recordings. The path can be changed subsequently in the Archive Player program for individual exports.

If you do not enter anything here, the following default setting is used:

%current user%\My Documents\Bosch\VIDOS\Export

**Maximum concurrent downloads**

Archive Player provides recordings from all available devices in the network locally on a PC and allows the corresponding files to be exported. Under certain circumstances, exporting recordings can result in a heavy network load. For this reason, you can limit the number of concurrent downloads here. This setting depends on both the local network's and the PC's specification.

**Maximum download attempts**

If a recording cannot be exported at the first attempt, Archive Player repeats the attempt several times. These attempts block other outstanding exports. For this reason, you can limit the number of download attempts here.

**Maximum download speed (%)**

The download speed can be adjusted.

**Resume aborted exports**

Select the **On** setting if you want aborted exports to be resumed when the program is restarted.

## 2.5.2 Layout

**Animate monitor layout change**

This function can be enabled or disabled here.

## 2.5.3 IntuiKey Keyboard

**COM port**

If the program is operated via an IntuiKey control panel, enter the number of the COM port here.

## 2.5.4 Playback

### Maximum trickplay instances

Dependant on your hardware's specification, you can select the number of playback instances on which you want to apply trickplay simultaneously.

### Enable smooth playback

This function can be enabled or disabled here.

## 2.5.5 VRM Server

### Connect to server

Activate this option if VRM Video Recording Management is being used on your system.

### Server IP address / IP address backup server 1 / IP address backup server 2

Enter the IP address of the VRM server and VRM backup server if applicable.

## 2.6 Preparing for the Exchange of Encrypted Data

To enable playback of encrypted data with Archive Player, you must adapt the settings for the relevant sender using Configuration Manager.

1. Select the **Devices** main tab in the Configuration Manager program and highlight the appropriate senders.
2. Select the **Network** tab from the display area.  
Activate the **Automatic key interchange** option under **Encryption**.  
Click **Set** to save the settings.
3. Select the **Unit access** tab.  
Select the **HTTPS** setting from the **Protocol** list field under **Device access**.  
Click **Set** to save the settings.


## 3 Operation

In the Archive Player program, you have access to all cameras that have previously been integrated into the system using Configuration Manager or VRM Configurator. Both programs allow you to combine cameras into groups, for example according to location. For more information, please see the appropriate documentation.

Archive Player provides the following functions:

- File search in all archives  
All recordings from a camera are listed. The recordings can be saved in the local memory of a sender (for example VideoJet X40), on NVR, on an iSCSI storage system or on your PC's hard disk. You can limit the search for recordings using filters.
- View  
Existing recordings can be played back on your PC. You can rewind and fast forward in a recording at variable speeds.
- Bookmarks  
You can set bookmarks at points that are relevant to you. This allows you to quickly find certain sequences in long recordings. The markers for alarm events are displayed and you can jump to them like to bookmarks.
- Forensic search in recorded video sequences (function requires license)  
Recordings can be analyzed for changes and movements with the aid of various algorithms.
- Export (function requires license)  
Recordings can be exported and burnt to CD or DVD.

## 3.1 User Interface



### No. Explanation

- 1 File search
- 2 Software zoom
- 3 Motion detection
- 4 Export
- 5 Playback window with monitors
- 6 Switch to VIDOS Lite Viewer  
(if installed via VIDOS Pro Suite)
- 7 Switch to Configuration Manager
- 8 Volume
- 9 CPU load display
- 10 Select/jump to markers

**No. Explanation**

- 11 Set bookmark
- 12 Print snapshot
- 13 Save snapshot
- 14 Control wheel (fast forward/rewind at variable speed)
- 15 Replay/pause
- 16 Search results
- 17 Timeline
- 18 Camera list
- 19 Additional options
- 20 Calendar

You can increase the space for displaying the search results and the timeline by placing the mouse at the upper edge of the appropriate section until the cursor changes into the following symbol:



With the mouse button held down, drag the upper edge up or down. The section view is increased or decreased and the size of the playback window changes accordingly.

## 3.2 Main Menu

Menu	Menu option	Explanation
<b>File</b>	<b>Open File...</b>	The selection dialog box for opening mp*-files is displayed. You can use this to select a recording that will then be displayed in the active monitor. Only recordings that have been saved from within a BVIP program or the Web browser view of a camera can be played back.
	<b>Check Authenticity...</b>	This function verifies whether the selected recording has been retrospectively manipulated.
	<b>Exit</b>	Closes Archive Player.
<b>Edit</b>	<b>Set Selection Start F5</b>	Sets the start marker for a selection.
	<b>Set Selection End F6</b>	Sets the end marker for a selection.
<b>View</b>	<b>Full Screen with Controls F11</b>	Toggles between full screen view with controls and window view.
	<b>Full Screen F12</b>	Toggles between full screen view and window view.
	<b>Layout</b>	Select the number and layout of displayed monitors. Predefined layouts are available.
	<b>Watermarking</b>	Shows/hides the watermarking icon of the recording. The icon can only be displayed if the overlay for the appropriate camera is already activated.

---

Menu	Menu option	Explanation
<b>Options</b>	<b>Trick Mode</b>	<p>Turns on trick mode.</p> <p>Trick mode ensures that all opened recordings can be played back synchronously.</p> <p>If you are using a mouse with a scroll wheel, you can view recordings frame by frame in trick mode. To do this, place the mouse cursor in the timeline below the timescale and turn the scroll wheel. Playback is automatically stopped (paused) during scrolling.</p> <p>Trick mode requires significantly higher memory capacity and computing power. For this reason, the number of cameras used in this mode can be restricted in the Configuration Manager program.</p> <p>(Details: <i>Section 2.5.4 Playback</i>, page 14)</p>

---

---

Menu	Menu option	Explanation
<b>Options</b>	<b>Automatic Leap</b>	<p>Here you can activate individual options, so that you can leap automatically only to specific points in recordings during playback. This allows you to remove uninteresting sections from playback and gain a quick overview.</p> <p>You have the following options:</p> <p><b>Video</b></p> <p>Leaps to the starting point of the next available recording. This is useful for devices that are set to record only at specific times or under specific conditions.</p> <p><b>Alarm</b></p> <p>Leaps to the next alarm event.</p> <p><b>Protected</b></p> <p>Leaps to the starting point of the next available recording protection.</p> <p><b>Activate All</b></p> <p>Leaps to all points described above in turn.</p> <p><b>Deactivate All</b></p> <p>Deletes the checkmarks before the selected options. The automatic leap function is deactivated.</p>

---

Menu	Menu option	Explanation
<b>Options</b>	<b>Automatic Monitor Assignment</b>	<p>In the default setting, each recording called up from within the search results is displayed on the active monitor. The active monitor is identified by a green border. The connection to a recording already running on this monitor is terminated.</p> <p>Select this option if each desired recording should be started on a separate monitor in turn. If all monitors displayed in the selected view layout are occupied, the selected recording is started on the monitor with the longest-standing connection.</p>
	<b>Help</b>	<p><b>Online Help...</b> Opens the online Help.</p> <p><b>About...</b> Provides information about the software version.</p>
	Switches to VIDOS Lite Viewer if this is installed on the PC via VIDOS Pro Suite.	
	Switches to Configuration Manager.	
	Gradually adjusts the volume for files being played back.	
	Shows the processor load on the computer. No exports are possible at loads above 50% (red).	

## 3.3 File Search

Here, you can search for recordings made within a particular time interval. You can set additional filters for the storage location and camera for your search.



### NOTICE!

As soon as you change one of the parameters for the file search (for example you select a different camera), a new search is automatically initiated.

### 3.3.1 Setting a Filter

When you start Archive Player, the current month is shown at the top of the file search tab. You can also find this display on the export tab.

1. Click  or  to display the previous/next month.
2. Click .
 

The calendar display is extended to include the next month and the filter options are displayed.
3. Click a day to highlight it
 

or

hold down the left mouse button and move the mouse over the desired days to select a longer period.

The selected period is highlighted in green.

4. You can enter a start and end time.  
If the selected period covers several days, the start time applies to the first selected day and the end time to the last. This allows you to accurately limit the selected period.
5. The **Filter** drop-down list allows you to limit the search to particular storage locations:



6. Select a camera from the camera list  
or  
select several cameras by holding down the **Ctrl** or **Shift** key while clicking them.  
If cameras are grouped in folders, for example by installation location, you can select a folder. In this case, recordings from all cameras in the folder will be searched and displayed.

As soon as you have finished the camera selection, the search for recordings begins. All recordings produced in the selected period using the selected camera(s) and stored at the selected location are listed as search results.

The camera itself does not have to be ready for operation or currently installed for existing recordings to be viewed. Only the devices on which the recorded data is stored (for example video sender with local storage medium, NVR) must be available in the network.

---

### NOTICE!



If you have changed the name of a camera but recordings from it are still stored in the system under the old name, these recordings are listed under the old camera name. However, the camera itself is marked as not available.

---

### 3.3.2 Search Results

Sort the saved recordings by clicking one of the column headers (**From**, **To**, **Source** or **Info**). A second click reverses the sort order. Use the scrollbars to scroll through the list.

In the first column, the storage location for the recording is indicated by an icon:



Recording is located on your PC.



Recording is located on NVR (Network Video Recorder) or in a VRM system.



Recording is located locally on the storage medium of an installed video sender (for example VideoJet X40).


▶ Click an entry.

Playback of the corresponding recordings is started.

## 3.4 Playback Controls

### 3.4.1 Timeline

The timeline is used for navigation. The green playback marker indicates the time at which the image currently displayed was created.



No.	Explanation
1	Camera name (active monitor in bold script)
2	Timescale
3	Period represented by the selected recording
4	Enlarge period
5	Reduce period
6	Bookmarks
7	Playback marker

Periods for which a recording is available are displayed in light gray.

The period displayed in the timescale can be changed:

- You can move the period displayed by moving the mouse along the timescale with the right mouse button held down.
- The displayed period can be enlarged or reduced by:
  - Clicking one of the magnifying glass icons in the right-hand margin
  - Placing the mouse cursor in the timescale above the timeline and turning the scroll wheel.

To view a different period, select a different recording from the search results or click another gray marker.

If several recordings are displayed, you will see a corresponding track with the relevant markers in the timeline for each monitor.




### Video scratching

Video scratching is useful for quickly searching large amounts of video data, for example if you are looking for one specific event.

To do this, drag the green playback marker above the camera track to the left or right with the right mouse button held down. During dragging, the I-frames on the associated monitors are updated, enabling a quick overview of the highlighted area.

### Popup menu

Right-click the camera tracks to open the following popup menu:




---

#### Zoom

An additional submenu is opened that allows you to select the period displayed in the timeline.

---

#### Add Bookmark...

Adds a bookmark at the position of the playback marker. The bookmark is added for all tracks. A dialog box appears, in which you can enter a brief explanation.

---

---

<b>Delete Bookmark</b>	Clicking an existing bookmark with the right mouse button gives you the option of deleting this bookmark. The bookmark is deleted for all tracks.
<b>Set Selection Start</b>	Adds a selection start marker at the position of the playback marker. Selection start markers can also be set from the main menu or by pressing <b>F5</b> . Selections are memorised when you switch to the Export module.
<b>Set Selection End</b>	Sets the end of a selection. Selections can also be created by moving the mouse cursor over an area of the timeline whilst holding down the left mouse button. Selections are deleted by clicking the timeline.
<b>Erase</b>	Deletes the previously selected video sequence from the memory. The deletion cannot be undone (only in VRM system).
<b>Protect</b>	Protects the previously selected video sequence from deletion. Protected sequences are indicated by a red marker (only in VRM system).
<b>Unprotect</b>	Removes protection for a sequence (only in VRM system).
<b>Export Selection</b>	Exports the selected sequence for all camera tracks displayed in the timeline (only in licensed Export function).

---

**NOTICE!**

If recordings are managed via VRM Video Recording Manager, some of the functions listed above may be limited due to the user rights assigned via the VRM system.

---

### 3.4.2 Viewing the Selected Recording

Once an entry has been selected from the search results, playback of the recording starts automatically.

**NOTICE!**

You can switch between the user interface and the full screen view by pressing the **F11** key for display with controls or the **F12** key for video display only.

---

**NOTICE!**

You can drag and drop a camera directly onto a monitor from the camera list. Playback begins at the starting point of the most recent available recording.

---

**Pause/replay**

Use this button to pause playback of the selected recording and click again to resume playback.

**Previous I-frame**

Jumps back to the previous I-frame.

**Next frame**

Jumps forward to the next frame.

---

**NOTICE!**

When jumping back, the last I-frame is displayed in each case. An I-frame is a complete picture produced regularly in a video stream, while the individual frames between them only record the changes. The frequency of I-frames is set on the video sender (details can be found in the manual for the relevant device).

---

### 3.4.3 Additional Information and Controls



#### Information

Here, you can see the time at which the recording was made. The current playback speed is displayed.



#### Control wheel (fast forward/rewind)

Fast forward or rewind the recording.

To do this, drag the control wheel to the left or right with the mouse button held down. The further you drag, the faster the recording is fast forwarded or rewound.



The control wheel can be locked in place for fast forwarding or rewinding a recording at a specific speed over a prolonged period of time. To do this, drag the green rectangle downward with the mouse at the position corresponding to the required speed. The rectangle will remain locked in place and the recording will fast forward or rewind until the rectangle is dragged upward again or until you click **Start**.



#### Save snapshot

Snapshots are saved in the folder that you specified in the Configuration Manager program.



#### Print snapshot

Before printing begins, the Print Preview appears. The snapshot is printed on the default printer.



#### Add bookmark...


Sets a bookmark at the current position. The bookmark is added for all tracks.

A dialog box appears, in which you can enter a brief explanation.



#### Previous

The playback marker leaps back to the nearest point in the recording that corresponds to the selection in the list field.



This list field is used to select the points to leap to when clicking the arrow icons. The following items are available:

- **All**
- **Video**
- **Bookmark**
- **Alarm**
- **Protected**
- **Frame**



#### **Next**

The playback marker leaps forward to the next point in the recording that corresponds to the selection in the list field.

### **3.4.4 Connection Between Monitor and Recording**

Connections between a recording and a monitor are established by:

- Dragging a camera from the camera list to the monitor
- Clicking one of the search results. The currently active monitor will be used for the new connection or, if the **Automatic monitor assignment** option is activated, the next monitor will be used.

Connections between a monitor and a recording are terminated by:


- Right-clicking the monitor and selecting **Disconnect Replay Session**
- Dragging another camera from the camera list to the monitor.

If you select a monitor layout with fewer monitors, some connections will be terminated.

Monitors can be moved with the mouse using the drag-and-drop function.

## 3.5 Software Zoom

The digital zoom tool allows you to display an enlarged view of a view port.



### No. Explanation

- 1 View port displayed with active zoom
  - 2 Activate/deactivate zoom
  - 3 Reset view port
1. Click **Activate zoom** to use the software zoom on the image on the active monitor.
  2. Move the mouse into the green rectangle. When the mouse cursor changes, you can hold down the left mouse button and move the rectangle to display a different view port on the active monitor.
  3. Drag any corner or side of the rectangle with the left mouse button held down to change the size of the selection rectangle.  
The view port on the active monitor changes accordingly.
  4. Click **Reset view port** to display the selection rectangle at the preset size and in the center.
  5. Click **Deactivate zoom** to show the entire image from the recording on the active monitor again.

## 3.6 Motion Detection

Various algorithms can be used to detect moving objects on recordings. This enables positions in which movements have been recorded to be found quickly, even in large volumes of video material. The only precondition is that motion detection was activated during recording.



### NOTICE!

Only sections highlighted as sensitive areas (shaded in yellow) during recording can be searched for movements.

---

The following algorithms are available:


- **MOTION+**  
License-free algorithm that detects movements in highlighted image areas. The sensitivity and minimum object size can be modified.
- **IVMD and IVA**  
These algorithms must be licensed after a demo period of 30 days.  
When using these algorithms, objects to be detected as moving can be defined exactly and filtered out according to factors such as size or speed.



### NOTICE!

These settings can only be edited if at least one monitor has been assigned a recording.

---



### No. Explanation

- 1 Saved configuration
- 2 Displays the outlines of moving objects on the active monitor, depending on the algorithm presets. Yellow outlines indicate a detected movement. Red outlines indicate a movement that has triggered an alarm event.
- 3 Displays the current configuration on the active monitor.
- 4 Enables changes to the configuration. The popup menu of the active monitor displays configuration editing options according to the selected algorithm.
- 5 Algorithm dropdown list
- 6 Opens a window for saving changed configurations.
- 7 Starts the movement search function according to the settings selected for the active monitor.

### NOTICE!



The configuration options for MOTION+ are described in the corresponding device manual.

Separate comprehensive documentation is provided together with the license documents for IVMD and IVA.

### 3.6.1 Motion Detection with Camera Presets

If a motion detection algorithm is configured and active during recording, the corresponding metadata is saved together with the video data. The alarm events generated with this preset are displayed in the recording as follows:

1. Select a camera from the camera list in the **File search** tab.
2. Select a recording from the list of search results.


3. Switch to the **Motion detection** tab: .

The **Search algorithm** display indicates which algorithm was active during the original recording.

4. Highlight the area to be analyzed in the timeline.

5. Click the  icon to search the highlighted selection for movements that have generated an alarm event.

Recognized events in the camera track are highlighted in yellow:



6. Click the  icon to display the motion detection configuration.

### 3.6.2 Forensic Search

If you want to search a recording with other filter settings, for example due to new findings, algorithms with self-defined settings can also be used for analyzing the sensitive area.

The MOTION+ algorithm is always available.

MOTION+ detects movements in a highlighted area of the camera image. The sensitivity and minimum object size can be set.

To continue using IVMD and IVA after the demo period of 30 days has expired, you must purchase a license and enter the license code using Configuration Manager.

Using the IVMD and IVA algorithms, objects can also be filtered according to their direction of movement, speed or behavior.



#### NOTICE!


After purchasing the license you will receive the *Forensic Search* documentation including detailed information on configuration options for the various algorithms.

---

#### Selection and configuration


1. Select a camera from the camera list in the **File search** tab.
2. Select a recording from the list of search results.
3. Switch to the **Motion detection** tab: .
4. Highlight the area to be analyzed in the timeline.
5. Select an algorithm from the **Search algorithm** list.
6. Click the  icon to display outlines of moving objects.
7. Click the  icon to display the current configuration.
8. Click the  icon to change the settings for the selected algorithm. The monitor frame is now displayed in yellow.
9. To open the popup menu, right-click in the active yellow-framed monitor.  
The popup menu offers different menu items, depending on the selected algorithm.
10. Change the algorithm parameters according to your requirements.

11. Click the  icon to save the settings as a preset. You can use saved presets for other recordings at a later date.
12. In the **Save configuration** dialog box, select the number (**1**, **2**, **3** or **4**) under which you want to save the preset. Give the preset a descriptive name.



13. Click the  icon to save the preset.
14. Click , ,  or  to apply a saved preset to the active monitor.
15. Click the  icon to search the highlighted selection for movements that have generated an alarm event according to the selected preset.

Recognized events in the camera track are highlighted in yellow:



16. Click  or  to jump to the previous or next alarm in the recording.



### NOTICE!

The detected alarm events are not saved if you terminate the connection between the recording and the monitor.

## 3.7 Export

The export module allows you to export all recordings to your PC or to a different storage location in the network. You can also burn selected recordings directly onto CD or DVD.




### NOTICE!

To use this tool, you must purchase a license. The **Export** tab is no longer available once the demo period has expired.

### 3.7.1 Exporting Recordings

1. Click the **Export** tab: .

You will see the export module:



**No. Explanation**

- 1 Calendar (with extended options)
- 2 Export Details
- 3 Export Status
- 4 Camera list
- 5 Search results
- 6 Destination
- 7 Export Format
- 8 Additional Information
- 9 Export items
- 10 Start burning process
- 11 Delete export job
- 12 Pause export

2. Search for the desired recordings.

(Details: *Section 3.3 File Search*, page 22)

The search results are listed.

All recordings that come from the same source are combined into a single entry. The **Info** column shows how many individual files from a camera have been found for the selected period.

3. Click the  icon next to the **Export Format** field. Select the desired format for the files to be exported.
4. Click the  icon next to the **Destination** field. You will see the **Browse folders** dialog box.
5. Select the folder in which you want the exported files to be saved.

Below the **Destination** field you will find information on how much memory space is available at the destination.

**NOTICE!**

Permanent settings for the export path are made using Configuration Manager.

---

6. Click **Export items**:



Exporting of the files begins.

Under **Export Status** you can see a list of all recordings that are currently being exported. Precise information about an export can be found under **Export Details** for a selected entry.

7. If you want to pause the export of individual files, select the corresponding entry under **Export Status** and click the



**Pause export job** icon:

8. If you want to cancel the export of individual files and delete those files, select the corresponding entry under

Export Status and click the **Delete export job** icon:



Recordings that are being burnt onto CD or DVD cannot be deleted.

9. Click the  icon again to continue the export.

---

### CAUTION!



In ring mode, it is possible that the originally selected recording will have been overwritten during the pause. In this case, the export cannot be continued.

---

### NOTICE!



No exports are possible at loads above 50% (display in menu bar turns red).

10. All exported recordings are listed under **Export Status**. After successful export, the message **Finished** is displayed under **Export Status** in the **Info** column.

11. If necessary, repeat steps 2 to 8 for other cameras or for a different period.  
The exported recordings are now stored at the destination location.

### 3.7.2 Export Markers

Recordings to be exported can be marked during playback so that the export module will only export a particular section of it.

1. Search for a recording (details: *Section 3.3 File Search*, page 22) and start playback.
2. Press **F5** when the playback marker is at the point where you want the export to start.  
The export start time is set.
3. Press **F6** when the playback marker is at the point where you want the export to stop.  
The export end time is set.



#### NOTICE!

You can also use the popup menu in the timeline to set start and end markers or highlight the required area by dragging with the mouse button held down.

The highlighted area is shown in green on the timeline:



4. Click **Export Selection** in the popup menu of the timeline.  
The highlighted sections are exported directly into the folder preset as **Destination** in the export module.  
Information on the exported sequences is displayed in a new window.
5. Click the  icon to close the window.
6. If necessary, switch to the export module to monitor the export process.

### 3.7.3 Possible Causes of Delays or Errors when Exporting

- Some devices can only establish one playback connection. This may already be in use.
- The recording no longer exists (overwritten in ring mode, file has been manually deleted).
- The network connection was broken during the export process.
- A recording you want to continue exporting has been opened on the PC in the meantime.
- The connecting point in a recording you want to continue exporting can no longer be found in the video stream.

Depending on the settings in the Configuration Manager program, Archive Player can make several attempts to export the files.



#### WARNING!

Do not delete the original recording data until you have made sure that the relevant data has been completely exported.

### 3.7.4 Additional Information

The name of a file to be burnt to a CD or DVD is derived from the names of the device and camera used to create the recording.

The file name can be edited before the burning process.

1. Click an entry in the list of exported files.

The **Additional Information** entry is now displayed above the export format information.



2. Enter your details (max. 32 characters) and click the  icon.

The file will be burnt to CD or DVD under the name entered.

### 3.7.5 Burning Data to CD or DVD

1. Insert a blank writable CD or DVD into the burner on your PC.
2. Under **Export Status**, select the recordings you want to burn onto CD or DVD. To do this, click in the box in front of an entry to mark it with a check:



You cannot select a recording until the export of that recording is complete.

The free memory space remaining on the CD or DVD is displayed next to the button.

3. Enter additional information for the selected entries (details: *Section 3.7.4 Additional Information*, page 41).



4. Click the **Start CD creation** icon: .



#### NOTICE!

This button is only available if at least one recording has been selected for export to CD. If one burning process is currently in progress, another cannot be started.

The data is burnt onto CD or DVD.

In addition, a program is burnt onto the CD or DVD that can be used to play back the video data on another PC.

## 4 Index

### A

Animation of layout change 13  
Archive 15

### B

Bookmark  
    setting 29  
Burning data to CD/DVD 42

### C

Camera list 17  
Checking authenticity 18  
COM port 13  
Configuration Manager 11  
CPU load 21

### D

Destination 38  
Download speed 13

### E

Encryption 14  
Export  
    delays 41  
    deleting 39  
    errors 41  
    file name 41  
    jobs 39  
    pausing 39  
    status 39  
Export markers 40  
Export path (Archive Player) 12  
Export to CD 42  
Export to DVD 42

### F

F11 key 28  
F12 key 28  
F5 key 40  
F6 key 40  
File search 22  
Filters 23  
Full screen 18, 28

### I

I-frame 28  
IVA 32  
IVMD 32

### L

Layout 18  
Leap filter 20  
License 9  
Limit  
    download attempts 13  
    file export 13  
    trickplay instances 14  
Login 7, 8

### M

Magnifying glass 25  
Monitor assignment, automatic 21  
Motion detection  
    own settings 35  
    presets 34  
MOTION+ 32

### O

Operation 15  
Outlines 33

### P

Password 7, 8  
Pause 28  
Play 28  
Playback marker 25  
Playback speed 29  
Program  
    exiting 18  
    starting 7  
Protect 27

### R

Replay 28  
Resuming exports 13

**S**

Search algorithm 35

Search results 24

Selection 27

Snapshot 29

Software 21

Software zoom 31

Symbols 3

**T**

Time of recording 29

Timeline 25

Trick mode 19

Trickplay 14

**V**

Version number 21

VIDOS Server 7

View 15

View port tool 31

Volume 21

VRM 8, 14

**W**

Watermarking 18

**Z**

Zoom, digital 31



**Bosch Security Systems**

Robert-Koch-Straße 100

D-85521 Ottobrunn

Germany

Telefon 089 6290-0

Fax 089 6290-1020

**[www.bosch-securitysystems.com](http://www.bosch-securitysystems.com)**

© Bosch Security Systems, 2007