ATM POS Service



en Installation Manual

ATM POS Service Table of Contents | en 3

Table of contents

1	Limitations	4
2	Prerequisities	Ę
3	Install the ATM POS Service	(
4	Start or Stop ATM POS Service	٤
5	Uninstall ATM POS Service	10

4 en | Limitations ATM POS Service

1 Limitations

The ATM POS Service does not support dynamic or runtime configuration changes. In
case of any configuration changes, the user first needs to stop the ATM POS Service. Use
the BoschATMPOSConfiguration tool to modify and to save the configuration changes in
the Service.xml file under C:\Program Files (x86)\Bosch\ATM POS Service. Restart the
ATM POS Service.

- 2. Multiple BVMS configured ATM Bridges (remote or local) in the Divar IP are not supported.
- 3. Before uninstalling the ATM POS Service, please back up the Device Configuration file (Service.xml). This file is deleted during the uninstall process.
- 4. To support multiple ATM device configurations, the ATM POS Device Port must be unique for each ATM device.
- 5. The ATM POS Service acts as a data conduit only. It does no data filtering into the BVMS system beyond what is covered by the DeviceID option.

2015.05 | 2.0 | Installation Manual Bosch Security Systems

ATM POS Service Prerequisities | en 5

2 Prerequisities


The following software packages should be installed on the Target Server Machine:

- Microsoft .NET 4.0.
- VC++ 2010 SP1 Redistributable

_

3 Install the ATM POS Service

1. Run **Setup.msi** on **Target Server Machine**. An ATM POS Service Setup Wizard dialog box should appear.




 Click Next to select the installation selection folder. The folder should default to C: \Program Files (x86)\Bosch\ATM POS Service. ATM POS Service | en




7

3. Click **Next** to continue the installation.



4. Click **Next** to continue the installation.

8




5. Click **Close** to complete the installation.

4 Start or Stop ATM POS Service

Prerequisite: Only start the ATM POS Service after complete configuration of the ATM POS in Service.xml. The BoschATMPOSConfiguration tool can be used to for the configuration changes that are described in the next section.

- 1. Start Task Manager.
- 2. Click the **Services** tab.
- 3. Click the Services button at the bottom to display the local services.
- 4. Select AtmPosService. Right click to Start/Stop/Pause/Resume/Restart the service.




5 Uninstall ATM POS Service

1. Go to the Control Panel. Select the option **Uninstall a program** under **Programs** group.



2. Select ATM POS Service. Click Uninstall button to start the un-installation process. Wait until un-installation to complete.



Bosch Security Systems, Inc. 850 Greenfield Road Lancaster, PA, 17601

www.boschsecurity.com © Bosch Security Systems, Inc., 2015 **Bosch Sicherheitssysteme GmbH**

Robert-Bosch-Ring 5 85630 Grasbrunn Germany