B308 Outputs Do Not Activate During Alarm Bell Test

September 9, 2014

Issue Severity:		Products Affected:
	High: Act immediately Medium: Bosch Security Systems strongly recommends you take the action(s) described below.	 B5512 v2.00.xxx B4512 v2.00.xxx B308 Octo-output Module
	Low: Advisory	

1.0 Issue

B5512/B4512 control panels with firmware version v2.00.xxx do not activate B308 outputs during the tests shown below. **Important!** The B308 **does** activate during an alarm or through other methods of output control (SKEDs, Menu, etc.).

The B308 does not activate outputs during these tests:

- Bell Test (during arming and closing ring back)
- Intrusion Walk Test (beginning of test)
- Fire Walk Test (beginning of test and as each point is tripped)

The B308 resumes normal operation after these tests.

2.0 Resolution

To resolve this issue, do **one** of the following:

• For Alarm Bells, use on-board Output A, B, or C.

-or-

• Update the control panel to firmware v2.01.xxx or higher. Perform the procedure below to access firmware updates from the website.

Downloading firmware updates:

- 1. Go to the Bosch website (us.boschsecurity.com).
- 2. In the Search text box on the right side of the page, enter the CTN (product name) for the product for which you wish to download the firmware.
- 3. Press [ENTER].
- 4. In the Search Results area, click the desired product's Product Page button. The product page opens with the Details tab selected.
- 5. Click on the Software Downloads tab, and then click the desired language listed to the right of the desired firmware.

Call Bosch Security Systems, Inc., Technical Support (1-800-289-0096) if you need additional assistance.



